


DG122S-1/4-E Extended Die Grinder Parts List



ATP

AIR TOOLS

PART LIST

NO.	CODE NO.	PARTS NAME	Q'TY	NO.	CODE NO.	PARTS NAME	Q'TY
1	001021080	Housing	1	26	SWBWW629	Washer	1
2	SC20506	Screw	1	27	OR4020	O-ring	1
3	030021080	Trigger	1	28	027031082	Front Casing	1
6	SP3022	Spring Pin	1	29	025011082	Spindle	1
7	SC60508	Screw	1	30	BR6900ZZ-2	Ball Bearing	2
8	010011080	Pin Valve Rod	1	32	035011082	Lock Nut	1
9	ORAS010	O-Ring	1	33	067011082	Bushing	1
10	007011080	Spring	1	34	066011028	Chuck	1
11	ORAS012	O-Ring	1	35	035031082	Collet Nut	1
12	009011080	Reverse Valve	1	36	W010P	Wrench	1
13	BR626ZZ-3	Ball Bearing	1	37	W011P	Wrench	1
14	011011080	Rear Plate	1	38	004021080	Exhaust Deflector	1
15	SP3008	Spring Pin	2	40	080011080	Air Strainer	1
16	012011080	Cylinder	1				
17	014011080	Blade	4				
18	013011080	Rotor	1				
19	015011080	Front Plate	1				
20	016011080	Washer	1				
21	BR6000ZZ	Ball Bearing	2				
22	017011080	Cylinder Set Screw	1				
23	035021082	Lock Nut	2				
24	018011082	Bushing	1				
25	040011082	Drive Bushing	1				

NOTE : Parts 24 and 25 must be ordered together

Assembled together of Bushing and Drive Bushing